

## Inspection Sheet 911 GT3/GT3 RS/GT2 RS

as of 2018 model

Name		Date										
License No.		Mileage/km										
		Repair Order										
Inspection		At 12,000, 24,000, 36,000, 48,000 miles/20,000, 40,000, 60,000, (For descriptions of the individual maintenance tasks, see PIWIS Information (For descriptions)			Vorks	shop N	Manual).					
Note		If the mileage for an inspection is not reached, an inspection must be out every 2 years at the latest.  The term 'checking' includes all necessary subsequent work, such as adjustments, readjustments, corrections and topping up, but does not include repairs, replacements or overhaul of parts or assemblies.  Measures	:	911 GT3	GT3 RS	GT2 RS	Every 12 tmls/20 tkm or 2 years	Every 24 tmls/40 tkm or 4 years	Every 48 tmls/80 tkm or 6 years	Every 72 tmls/120 tkm or 4 years	Every 96 tmls/160 tkm or 12 years	Time-dependent
							鱼	山	山	山	血	<u> </u>
	Electrics	Windshield wiper/washer system, headlight cleaning system: check fun	ction	•	•	•						
		Horn: check function		•	•	•						
		Tires: check tire pressure (TPM)		•	•	•						
		Diagnostic system: read out fault memory; reset maintenance interval		•	•	•						
		Check parking brake actuator travel  Water spray system: perform drive link test		•	•	•						
		vvater spray system. perform unive link test										
	e pe	Pollen filter: replace filter element		•	•	•						
	Inside the vehicle	Seat belts: check function and condition		•	•	•						
	su ×	Door locks: check function		•	•	•						
		Check front lid lock and safety hook of the front lid to ensure that they a and function properly	re secure	•	•	•						
	Luggage compartment	Replace air intake pre-filter		•	•	•						
		Windschield wiper/washer system: check fluid level; check window clea antifreeze, depending on time of year, only use windshield cleaners appr Porsche		•	•	•						
		Check front firewall body drains for debris				•						
		Water spray system: change filter				•						
		Water spray system: check fluid level				•						

Relevant model line

Part Number: PNA 000 162 FN

Carry out depending on mileage/age (Please check)



## Inspection 911 GT3/GT3 RS/GT2 RS

as of 2018 model

		Measures	911 GT3	GT3 RS	GT2 RS	Every 12 tmls/20 tkm or 2 years	Every 24 tmls/40 tkm or 4 years	Every 48 tmls/80 tkm or 6 years	Every 72 tmls/120 tkm or 4 years	Every 96 tmls/160 tkm or 12 years	Time-dependent
		Check wiper blades	•	•	•						
		All headlights: check adjustment	•	•	•						
	Outside the vehicle	Radiators and air intakes: visual inspection for external contamination and blockage	•	•	•						
	utside th	Brake system*: check brake pads and brake discs for wear	•	•	•						
	0	Brake system: check brake pads and brake discs for wear (without removing wheels)	•	•	•						
		Check central lock on wheels	•	•	•						
	Under the vehicle	Drain engine oil (See separate Oil Maintenance Sheet PNA 000 162 FP)	•	•	•						$\equiv$
		Change oil filter	•	•							
		Underbody panels: visual inspection for completeness, secure installation and damage	•	•	•						
		Tires: check condition	•	•	•						
		Visual inspection for leaks from underneath (oils and other fluids)	•	•	•						
		Brake lines: visual inspection for damage, routing and corrosion	•	•	•						
		Brake hoses: visual inspection for damage	•	•	•						
		Steering gear: visual inspection of the bellows for damage	•	•	•						
		Tie rod joints: check play and dust bellows	•	•	•						
		Drive shafts: visual inspection of the boots for leaks and damage	•	•	•						
		Axle joints: check the play and visually inspect the dust boots for damage	•	•	•						
		Rear-axle steering: check bellows, dust boots and play on joints	•	•	•						
		Anti-roll bar and connecting links: visual inspection for damage		•	•						
		Check that threaded connections for chassis adjustment at front and rear are secure	•	•	•						
		Check vehicle height	•	•	•						
		Control boxes for exhaust flaps: check function	•	•	•						

<sup>\*</sup> Vehicles with PCCB: PCCB Brake discs must be checked for wear during every service and whenever brakes pads are replaced using special tool VAS 6813.

Relevant model line

©2018 Porsche Cars North America, Inc.

Edition 3/18

Part Number: PNA 000 162 FN

Carry out depending on mileage/age (Please check)



## Inspection 911 GT3/GT3 RS/GT2 RS

as of 2018 model

		Measures	911 GT3	GT3 RS	GT2 RS	Every 12 tmls/20 tkm or 2 years	Every 24 tmls/40 tkm or 4 years	Every 48 tmls/80 tkm or 6 years	Every 72 tmls/120 tkm or 4 years	Every 96 tmls/160 tkm or 12 years	Time-dependent
	Under the vehicle	Exhaust system: visual inspection for leaks and damage, check engine mount	•	•	•						
		Replace spark plugs	•	•	•						
		PDK transmission: change clutch fluid	•	•	•						
***		PDK transmission: change transmission oil	•	•	•						
		Manual transmission: change oil	•								
		Ancillary unit mounts and chassis: visual inspection of all rubber mountings and boots for damage	•	•	•						
000	Engine compartment	Fill in engine oil (See separate Oil Maintenance Sheet PNA 000 162 FP)	•	•	•						
		Coolant: check level and antifreeze	•	•	•						
		Replace drive belt	•	•	•						
	Engine npartme	Fuel lines and connections: visual inspection	•	•	•						
	00	Air cleaner: replace filter elements	•	•	•						
		Check rear firewall body drains for debris	•	•	•						
<b>+</b>	Additional work every 2 years	Change brake fluid (use only original Porsche brake fluid)	•	•	•						
		Tire sealing compound: check use-by date and replace if necessary	•	•	•						
× ×	Test drive	Remote control, front seats, electric parking brake and foot brake (also actuation travel), engine, steering, transmission, cruise control, ESC Off switch, ESC + TC Off switch, PASM switch, Sport switch, Lift switch, sports exhaust system, heating, air conditioning and instruments: check function	•	•	•						
		Oils, fluids: visual inspection for leaks	•	•	•						
Cianatura (t				1							

Relevant model line

©2018 Porsche Cars North America, Inc. Edition 3/18

Porsche Dealer Stamp

Part Number: PNA 000 162 FN

Carry out depending on mileage/age (Please tick)