

Maintenance Checklist – 911 GT3/GT3 RS (991) (2015-16)

Required Maintenance and Lubrication Service

- * **Oil Change** Every 12,000 miles (20,000 km) or 1 year. Built up to week 44/2014 **See Below Check Box.**
- Oil Change** Every 6,000 miles (10,000 km) or 1 year. Built from week 45/2014 **See Below Check Box.**

Maintenance (Labor Operation 03 14 00 ..) See Technical Manual
After 24,000, 48,000, 72,000, 96,000 miles (40,000, 80,000, 120,000, 160,000 km) etc.

Note: If the mileage for scheduled maintenance is not reached, intermediate maintenance must be performed no later than after 4, 8, 12..... years.

The terms 'check' and 'inspection' include all necessary subsequent work such as adjusting, readjusting, correcting and topping off, but do not include repairing, replacing and reconditioning parts or assemblies.

Electrics

- Diagnosis system: Read out fault memory; reset maintenance interval
- Windshield wiper/washer system, headlight washer: Check function and nozzle adjustment
- Horn: Check operation
- Tires: Check tire pressure (TPM)
- Electrical equipment as well as indicator and warning lights: Check operation

Inside of Vehicle

- Pollen filter: Replace filter element
- Seat belts: check function and condition
- Door locks: check function

Front Luggage Compartment

- Pollen filter: Replace pre-filter element
- Check front lid lock and safety hook of the front lid for secure seating and function properly
- Windshield wiper/washer system, headlight washer: Check fluid level and antifreeze protection level
- Check firewall body drains for debris

Outside of Vehicle

- Check wiper blades
- Vehicle lighting: Check operation
- All headlights: Check adjustment
- Radiators and air intakes: Visual inspection for exterior debris and blockage
- Check central lock on wheels

Under the Vehicle

- Drain engine oil
- Vehicle underside and engine compartment: Visual inspection for leaks (oils and fluids) and abrasion (lines and hoses); Underbody panels: visual inspection for completeness, secure installation and damage
- Tires: Check condition
- Brake system: Visual inspection of the brake pads & brake discs for wear (w/o removing wheels) (Except PCCB)
- Vehicles with PCCB: Brake discs must be checked for wear during every service and whenever brakes pads are replaced using special tool VAS 6813. Please refer to workshop manual for work procedure.
- Brake hoses and lines: Visual inspection for damage, correct routing and corrosion Check brake fluid level
- Steering gear: Visual inspection of the dust boots for damage
Tie rod ends: Check play and dust boots
- Axle shafts: Visual inspection of the dust boots for leaks & signs of damage
- Rear axle steering: Check bellows, dust boots and joints for play
- Check that threaded connections for front & rear chassis adjustment are secure
- Check vehicle height
- Exhaust system: Visual inspection for leaks and damage; check mounting and heat shields
- Control boxes for exhaust flaps: Check function

Engine Compartment

- Change oil filter and fill engine oil (Every 12,000 miles/20,000 km, see separate Oil Change Sheet, PNA 000 162 FJ) **Up to week 44/2014**
Change oil filter and fill engine oil (Every 6,000 miles/10,000 km, see separate Oil Change Sheet, PNA 000 162 FM) **From week 45/2014**
- Air filter GT3: Replace filter elements
Air filter GT3 RS: Replace filter elements every 6,000 miles (10,000 km) See Oil Change
- Replace drive belt
- Fuel lines and connections: Visual inspection for damage and leaks
- Coolant: Check level and antifreeze protection level
- Check firewall body drains for debris

Additional Maintenance – Replace Spark Plugs (Labor Operation 03 81 00 ..)

Replace spark plugs: every 12,000 miles / 20,000 km or 2 years

Additional Maintenance every 48,000 miles / 80,000 km or 6 years (Labor Operation 03 82 00 ..)

PDK transmission: change clutch oil

Additional Maintenance every 80,000 miles / 120,000 km or 4 years (Labor Operation 03 85 00 ..)

Ancillary unit mounts and chassis: visual inspection of all rubber mountings and boots for damage

Additional Maintenance every 96,000 miles / 160,000 km or 12 years (Labor Operation 03 86 00 ..)

PDK transmission: change oil

Additional Maintenance every 2 years (Labor Operation 03 51 00 ..)

- Change brake fluid (use only Original Porsche Brake Fluid)
 - Tire sealant (check expiration date and replace as necessary)
-

Inspection Performed - Technician Signature: _____

Road Test Check

- Remote control, front seats, foot brake (also operating travel) and electric parking brake, engine, clutch, steering, transmission, cruise control, ESC Off switch, ESC + TC Off switch, PASM switch, PDK Sport switch, PIT SPEED switch (GT3RS), Lift switch, sports exhaust system, air-conditioning system and instruments: Check operation
 - Oils, fluids: Visual inspection for leaks
-

Road Test Performed - Technician Signature: _____

Customer Name: _____ **Date:** ____/____/____

VIN: WPO _____

Mileage (check one) **Miles** **Kilometers:** _____

Dealer Name: _____ **Dealer Code:** _____

Repair Order #: _____

Technician Name: _____

Technician Signature: _____